




Verizon Ellipsis 7 Rear Facing Camera Replacement

This guide will show you how to remove the rear facing camera on the Verizon Ellipsis 7 tablet.

Written By: Charles Gorbett



INTRODUCTION

This guide will show you how to replace a rear facing camera on a Verizon Ellipsis 7 correctly. This is vital in taking pictures from the back of your device. This guide will require extra precautions, as you are going to have to take out the main motherboard. Performing the actions in this guide incorrectly could break your device.



TOOLS:


- [Phillips #00 Screwdriver](#) (1)
- [Heavy-Duty Spudger](#) (1)
- [Tweezers](#) (1)
- [iFixit Opening Tools](#) (1)



PARTS:

- [Verizon Ellipsis 7 Rear-Camera Replacement](#) (1)

Step 1 — Charging Port




- Hold down the power button until the screen goes black to turn off the device.
- Remove the SIM card from the device to prevent damage.
 - To remove the SIM card, open the SIM card cover on the side of the device.
 - Push SIM card in and pull it out after hearing a click.


Step 2



- Take off the back panel.
- Pry open the back cover carefully with a plastic opening tool.
- Use the opening tool to disconnect the cover completely. Do not attempt to pry the back cover off with your hands.

 Be sure to pry open all sides of the device. Attempting to take off the back cover when part of it is attached may snap the cover.



Step 3



- Remove the charging (micro-USB) port.
 - Unscrew the indicated screws using the Phillips #00 screwdriver.
 - ⓘ The screws shown in the picture are the more common 4.76 mm.
- Disconnect the ribbon cable connecting the charging port board to the motherboard using tweezers.
 - Use the tweezers to grab the sides of black, plastic connector. Do not grab from the wires or try to wedge it out from the bottom.



⚠ Be extremely careful when disconnecting the ribbon cable. It is very delicate.

Step 4




- Remove the charging port board from the phone using tweezers.
 - Place the replacement charging port into the phone.
- ⚠ Be cautious when replacing the ribbon cable onto the new charging port board.

Step 5 — Speaker




- Remove 2 screws from each speaker, 4 screws in total, using a Phillips #00 screwdriver.
- ⓘ The screws shown in the picture are the more common 4.76 mm.

Step 6




- Using tweezers carefully lift the connector up to disconnect it from the motherboard.
- Using tweezers carefully pull the speakers up and out of device.

Step 7 — Rear Facing Camera




- Use the tweezers to carefully disconnect the power cable bundle from the motherboard.

Step 8




- Remove the 10 screws from the motherboard using a Phillips #0 screwdriver.
 - ❗ The screws shown in the first picture are the more common 4.76 mm.
 - ❗ The screw shown in the second picture is shorter, 3.175 mm, than the rest of the screws

Step 9




- Remove the 5 antenna cable connectors from the motherboard using a spudger.

Step 10



- Disconnect the two ZIF connectors that are connected to the motherboard with a spudger. Lift up the metal part of the connector and then pull the connector off of its port
- Once disconnected pull away from its connector carefully with tweezers.
- Once the connectors have been disconnected you can gently lift up on the motherboard to remove it from the device.

Step 11



- Remove the motherboard from the tablet.
 - ⓘ Use the spudger to disconnect the press lift connector.
- Carefully flip the motherboard over. Disconnect the camera at the top of the board using tweezers.

To reassemble your device, follow these instructions in reverse order.

